M06-INSV1



MIRRORED CABINET ASSEMBLY INSTRUCTIONS

PRECAUTIONS

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble or install the product.


Safety discard all packing material. Keep plastic bags and small parts away from children. Safety glasses should be worn at all times. Do not load this cabinet with more than 50 lbs. Do not load each shelf with more than 25 lbs.

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes (with recommended two-person installation).







PRECAUTIONS




Mark holes based on the desired location, then drill holes and fix mounting bar on the wall




Install the holder,then install side panel.




Install glass shelf board and cover plate according to diagram.






Adjust door position accordingly.



RECESSED MOUNT INSTALLATION



CARE AND MAINTENANCE

Cleaning and Care

Use of a residential glass cleaner such as Windex, Zep Streak-Free Cleaner or other spray on glass cleaner. Follow the directions on your selected cleaning product, with a liberal application of the cleaning solution. Using a lint free or microfiber cloth and remove the cleaning solution in a gentle circular motion. If the mirror feels "tacky" while cleaning, simply apply more cleaner.

Never clean the mirror with a lint free cloth WITHOUT cleaning solution.

Do not use cleaners which include fragrances, oils, acids, alcohols, bleach, or abrasive particles.

Do not clean with a scouring pad, rough cloth, abrasive paper towel or window scraper.

TROUBLESHOOTING		
PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
The doors are not aligned.	The hinges are misaligned.	To adjust the doors right or left, loosen/tighten the screw as in (a). To adjust the doors in or out, loosen/tighten the screw as in (b). To adjust the doors up or down, loosen/tighten the screws as in (c).

MAINTENANCE

ONE-YEAR LIMITED WARRANTY

Products are warranted to be free of defects in material and workmanship for one year from date of installation.

We will, at its election, repair, replace or make appropriate adjustment any such defects occurring in normal usage within one (1) year after installation. We are not responsible for removal or installation costs.

Questions, problems, missing parts?

If you are missing any part, please stop and contact us immediately. Contact Email address: sales@deluxelivinghome.com Or call our customer service department 1-888-680-0215 at 9 a.m.-5 p.m., Monday - Friday. Visit Website: http://www.deluxelivinghome.com for more details.

